

VIEW 6S

Exclusive core alignment fusion splicer

Core alignment splicing method with DACAS (Digital Analysis Core Alignment System)

The highest magnification and resolution

5" LCD color touch screen

Double tap (zoom in & out)

Fast heating time

Short cleave length splicing capability

Detachable SOC holder and heating oven

Suitable for working in the Deutsche Telekom network





Short V-groove: 5 mm cleave length splicing capability



Fast heating up to 13 sec



Detachable heating oven for SOC



3 bright LEDs for dark environment



Ceramic clamp—Improved durability



Changeable holder for multi-functional splicing



5.0" Touch screen with smart GUI
The highest 520x magnification
Double tap to zoom in & out
Clear core image



touch

View 6S, a core alignment fusion splicer with the highest fiber image magnification ratio in the world, is the exclusive fusion splicer presented only to major telecommunications operators. View 6S's high-resolution 5-inch LCD color touch screen with an intuitive and user-friendly graphical interface (GUI) provides users with large and clear fiber optic images. By double-tapping on the screen, users can enlarge and reduce the image with a magnification of 520×.

He also meets all the requirements of the "ZTV-TKNetz 48" and is therefore suitable for all work in the Deutsche Telekom network.

View 6S offers maximum working efficiency thanks to a fast heating time of 13 seconds. View 6S provides a satisfying work experience for its users in the FTTx field, which is compatible with widely used fiber optic cables, and the short V-groove length allows the splicer to splice a 5 mm slot length suitable for the connector to be spliced. In addition, the 3 LED lights present a bright splicing condition for users working in dark environments.

View 6S offers the most reliable work experiences with customized solutions for our valued customers.

Specifications

Model	View 6S
Number of fiber	Single
Applicable fibers	SM (ITU-T G.652 & G.657) / MM (ITU-T G.651) / DS (ITU-T G.653) / NZDS (ITU-T G.655)
Compatible fiber / cable	0.25–3.0 mm / Indoor cable
Cleaved length	Diameter: 0.125–1 mm / Cleaved length: 5–16 mm
Cladding diameter	80–150 μm
Splicing mode	Maximum 128 modes
Heating mode	Maximum 32 modes
Typical splice loss	SM: 0.02 dB / MM: 0.01 dB / DS: 0.04 dB / NZDS: 0.04 dB / G.657: 0.02 dB (ITU-T Standard)
Splicing time	Quick mode: 7 seconds / Auto mode: 9 seconds
Heating time	Typical 13 seconds
Heating sleeve length	20–60 mm
Return loss	>> 60 dB
Estimated splice loss	Available
Display	90° bi-directional view, 5.0" High resolution color display
Fiber view & magnification	X, Y, XY, X/Y: 520× magnification
Results storage	The last 10,000 results (Values + photos)
Tension test	1.96–2.25 N
Operating methods	Button / Touch screen
Lighting	3 white LEDs
Power supply	AC Input 100–240 V, DC Input 9–14 V
No. of splice & heating with battery	4,200 mAh battery capacity / Typical 170 times (Splice + heat)
Automatic calibration	Automatic arc calibration by air pressure and temperature
Electrode life	5,500 arcs, can be extended by using an electrode grinder
Terminal	USB 2.0 / MINI USB
Operating condition	Operating altitude: 0–5,000 m above sea level / 0–95 % relative humidity / –10–50 °C / Max. wind 15 m/s
Storage condition	0–95 % relative humidity / –40–80 °C
Dimensions in mm (Height×Width×Depth)	152×147×175 (including rubber bumper)
Weight	2.07 kg (without battery) / 2.43 kg (with battery)



Weight and dimensions



Height: 5.98" (152 mm)
Width: 5.78" (147 mm)
Depth: 6.88" (175 mm)
Weight: 4.56 lbs (2.07 kg without battery)

Detailed view



Delivery contents

Fusion splicer	View 6S
High precision cleaver	V7+
Fiber holder	VFH-40S (equipped) / FH-SOC-3.0
SOC heater cover	HT-SOC
AC adapter	JS-180300
Cooling tray	CG-22
Electrode	E-50
Battery pack	LBT-50
Power cable	ACC-25
USB cable	USB-5P
Cigarette lighter cable	CJ-11
Carrying case	NBX-35

Accessories

In addition to the splicer, various tools are required for the correct preparation of the fibers. If you are not yet equipped for this, we are of course happy to help.

Whether it's a suitable stripper, a loose tube cutter, cleaning fluid and cloths or a crimping press, we can provide everything. And we're here to help and advise you. Talk to us or get an initial overview online.

The information contained in this catalogue is subject to change without notice.

Splicing technology in the web shop: www.kws-electronic.shop

Splicing technology on our website: www.kws-electronic.com

KWS Electronic Test Equipment GmbH

Tattenhausen · Raiffeisenstraße 9 · 83109 Großkarolinenfeld · Germany
Phone 00 49 .(0) 80 67 .90 37-0 · Fax 00 49 .(0) 80 67 .90 37-99
info@kws-electronic.de · www.kws-electronic.com

